

Mouse Not Working HELP

For some reason my cursor will not move on my laptop, even when I use a mouse.....Any suggestions?>>

Answer: IF it doesn't move when you use the synaptic mouse built into the laptop, it's because someone has turned it off.

If a regular PS2 mouse is plugged into a USB port and it won't move the cursor...it's because the driver for the mouse has not been loaded.

Try this:

Check PS2 USB Mouse:

- 1. Rightclick My Computer and select Properties.**
- 2. Click Device Manager**
- 3. Scroll down to Mouse, click the plus to see if both the laptop's mouse and the PS2 mouse or listed. Rightclick the PS2 mouse and select Delete.**
- 4. Now, with the PS2 mouse plugged into a good USB port on the laptop, restart your computer. The computer should find the PS2 mouse. Wait a moment, It should then say "new hardware found, driver loaded and ready for use".**
Now you should be able to use the PS2 mouse.

For activating the Synaptic Mouse on the laptop:

- 1. Rightclick START and click RUN**
- 2. Type MSCONFIG and click OK.**
- 3. Click STARTUP and scroll down and put a check in the box for the Synaptic Mouse so it loads each time you start the laptop.**
Now the Synaptic mouse on your laptop should be activated and ready for use.

You can have both the Synaptic mouse and a PS2 or other Mouse activated and use either or at any time, if you prefer.

Revised 3/13/2013 jMM