

Linksys Wireless Laptop Card Fails to Connect

When the Wireless Card will not connect to the internet using the default setting, try this:

Bring up MSIE and type into the browser box 192.168.1.1 and click GO to reach the Linksys web site.

Click WIRELESS....WIRELESS SECURITY

At the WEP that has the dot in it, type the numbers of the WEP code, Click GENERATE.

It should then generate the same number as the one you see on your wireless connect screen.

Go back now and again bring up MSIE and see if you can get online.

Revised 6/7/2009 JMM