

## COMPUTER'S LOSS OF TIME

If your computer loses time, use the **Date/Time** tool to set the correct time:

1. Click **Start**, point to **Settings**, and then click **Control Panel**.
2. Double-click **Date/Time**.
3. On the **Date & Time** tab, configure the correct time, and then click **OK**.

To determine if the time loss is a result of a weak computer battery:

1. Click **Start**, point to **Programs**, and then click **MS-DOS Prompt**.
2. At the command prompt, type `time`, and then press ENTER.
3. Compare this time with the time that is reported by the clock on the taskbar.
4. Type `exit`, and then press ENTER.

If the computer's time and the time on the clock are different, the computer's battery may be too weak to keep accurate time, and it should be replaced. For information about how to replace the battery, refer to the documentation included with your computer.

**NOTE:** This problem does not affect the clock in your computer's CMOS.

(See Microsoft's knowledge base article: <http://support.microsoft.com/?kbid=189706&fr=1>.)  
Information in this article applies to: Win98SE, Win98, Win95, Win ME. XP