

Disable the Numeric Keypad

The alpha/numeric keypad on a laptop is controlled by the numloc key located somewhere at the top right of your laptop keyboard.

Numloc ON turns numeric on and you may now use the numeric section of the keyboard just as you did the numbers keypad on a regular keyboard. Holding down the FN key will allow you to type letters instead of the number.

Turn OFF numloc and that area of the laptop keyboard once again is alpha. Holding down the FN key will not allow you to type a number since you already have option to type numbers.

Revised 1/23/2011 JMM